

TOP SPRING ASSIST INSTALLATION INSTRUCTIONS

- When installing always use the bottom spring that is installed by the manufacturer first. If there is not enough tension add the top spring.
 1. First install flat washer on the pipe at the top of the door.
 2. Add the spring and another flat washer.
 3. Install V-cam base.
 4. Slip the follower on.
 5. Line the door up in the jamb then start putting in your screws in through the V-CAM base back plate and spacer.
 6. Tighten down. *Make sure your V-CAM base is centered in opening and your jamb guard at the bottom is centered.*
 7. Make sure your door is at the right height. *You can use a wood 2 x 4 on the floor to set the door height.*
 8. Tighten up the set screw in the floor and test the door.
 9. Remove the 2 x 4 and make sure that it swings and returns to center then drill a hole in the follower and set the pin.
 10. Door is successfully installed.